



promate.net Lifestyle Technology

aquaBox

Rugged Bluetooth™ Portable Speaker
with Handsfree Function, Water and Dust resistant



User Guide

Introduction:

Thank you for purchasing Promate aquaBox, a universal Bluetooth™ 3.0 water resistant speaker built for adventure. The IPX5 level water resistance ensures the speaker is safe from splashes whether on a boat, by the pool or in a tub. The easy to use controls on the side of the device lets you control your music or answer calls at the press of a button. Its Bluetooth™ 3.0 feature allows you to sync with any Bluetooth™ enabled device such as an iPad, iPhone, iPod, Android devices etc. from up to 33 feet. The powerful 800mAh rechargeable battery lets you listen to your favorite tunes uninterrupted for 4 hours. aquaBox, a product built for adventure enthusiasts.

Packaging contents:

- aquaBox
- Micro USB charging cable
- AUX cable
- User Guide
- Warranty card

Specifications

- Output: 3W (RMS)
- Battery: 800mAh
- Bluetooth™ version: 3.0
- Impedance: 4 Ohms
- Speaker Frequency: 100~15000Hz
- Mic Sensitivity: $-42 \pm 3\text{dB}$
- Charging time: 3-4 hours
- Play / Talk time: 4 hours
- Effective Distance: 10 meters (33 ft.)
- Water-Resistant IPX5 certified;

Features:


- Streams music wirelessly from any Bluetooth™ enabled device
- Answer phone calls wirelessly from any Bluetooth™ smartphone
- Syncs with iPad, iPhone, iPod touch, Android devices and more, up to 33 feet away
- Easy-to-use controls for music playback and answering phone calls
- IPX5 level water resistance
- Perfect for listening to music on a boat, by the pool, in a tub, and more
- Built-in powerful 800mAh rechargeable battery that ensures 4 hours of playback

Precautions

Please read all safety instructions and warnings thoroughly before using this product. Improper use of this product may result in damage to this or attached products.

- Do not disassemble the device or attempt to fix it.
- Kindly use the included Micro-USB Cable to charge the product.
- Do not attempt to replace any part of this case or battery inside.
- Do not crush, puncture or dispose of in fire.
- Do not store or use the battery in a high temperature environment, including intense sunlight or heat.
- Avoid excessive drops, bumps, abrasions and impacts.
- If there is any reason to believe that there is internal damage to the device, discontinue use immediately.
- If you find that the device is too hot, is emitting an odor or is deformed, punctured or exhibits any suspicious or abnormal behavior, discontinue use immediately and contact our customer service.
- Always charge this product before extended storage.

Appearance & Interface Description:



- 1 Power Switch
- 2 One Touch Handsfree
- 3 Volume Control
- 4 AUX In
- 5 Micro-USB Charging Port
- 6 LED indicator



Operation Instructions:

Charging aquaBox

1. Connect aquaBox to a PC/Laptop/Mac or 5V USB adaptor (not included) with the USB cable included
2. Red LED turns ON during charging, turns OFF after the device is fully charged.
3. Red LED twinkles when the device has low power.

Pairing aquaBox with mobiles (Bluetooth™ enabled) and Tablets.

1. Turn on aquaBox using the power switch
2. The white & red LED starts blinking, the speaker is standby for pairing.
3. Turn on the Bluetooth™ function on your phone and search for "aquaBox" in the available device list.
4. Pair the device to your phone using the passkey (0000)
5. After successful pairing, LED changes to solid white.

Pairing aquaBox with PC or notebook

1. Turn on aquaBox using the power switch
2. The white & red LED starts blinking, the speaker is standby for pairing mode.
3. Run Bluetooth™ program on your system.
4. Turn on the Bluetooth™ function on your system and search for "aquaBox" in the available device list
5. Pair the device to your system using the passkey (0000)
6. After successful pairing, LED changes to solid white

Pairing aquaBox with Mac OS X 10 or above

1. Turn on aquaBox using the power switch
2. The white & red LED starts blinking, the speaker is standby for pairing.
3. Click setup Bluetooth™ Device from the Bluetooth™ status menu in the menu bar, and follow the onscreen instructions to pair with the speaker. (If the Bluetooth™ status menu is not available, open Bluetooth™ Preference and select the “Show Bluetooth™ status in the menu bar” checkbox.)
4. Pair the device to your system using the passkey (0000)
5. After successful pairing, LED changes to solid white

Answering Calls

1. Short press the “One touch Handsfree” button to answer the phone call.
2. Short press again to end a call.

Volume control

Control volume via the paired devices, such as iPhone, iPad, Mobile phones, PC/Mac...etc. or even using the volume rocker buttons on the device.

AUX port

Connect an external player to the aquaBox by connecting the player to the aquaBox AUX port using AUX cable provided.



www.promate.net